

Brock's Performance • 4064 E. Patterson Road • Dayton, OH 45430 • Phone: 937-912-0054 • Fax: 937-912-0062

ZX-10R (16-25) CARBON FIBER MIRROR BLOCK OFFS PRODUCT INFORMATION

Carbon Fiber Mirror Block Offs are designed to replace the OEM side view mirrors. Removal of the OEM side view mirrors will reduce weight and aerodynamic drag. Carbon Fiber Mirror Block Offs are used to cover the holes and secure the front windscreen cowling.

Package Contents:

ZX-10R Mirror Block Offs shown:

- 1. One (1) Right Carbon Fiber Mirror Block Off
- 2. One (1) Left Carbon Fiber Mirror Block Off
- 3. Four (4) Black Aluminum Screws
- 4. Four (4) Nylon Washers

If your package contents differ, please contact Brock's Performance at 937-912-0054.

For additional installation support please refer to the OEM service manual.



Installation Notes:

NOTE: This product is **NOT DOT** approved for street use.

- 1. Remove the left and right inner covers (dash panels).
- 2. Disconnect the left (black) and right (grey) turn signal connectors.
- 3. Remove four (4) bolts securing left and right side mirrors.
- 4. Remove OEM left and right side mirrors.
- Install Carbon Fiber Mirror Block Offs and Nylon Washers using the supplied black aluminum screws.



Note: The Nylon Washers go between the body plastic and the Carbon Fiber Mirror Block Off.

- 6. Torque black aluminum screws to 72 in-lb. (8 N·m).
- 7. Install the left and right inner covers.

ALL BROCK'S PERFORMANCE PRODUCTS ARE DESIGNED FOR CLOSED-COURSE RACETRACK USE ONLY!

For more information on Brock's Performance Warranty and Terms and Conditions:

BrocksPerformance.com > Brock's Support > Customer Service > Terms and Conditions

For Questions and Comments:

BrocksPerformance.com > Brock's Support > Customer Service > Contact Us or call 937-912-0054